

The source and chemical composition of blind samples are known to the submitter although typically not known to the analyst; therefore, blanks, SRS, or reference material usually are used as blind samples. Blind samples can be designed to answer questions such as "What bias and variability are introduced by procedures used within a single laboratory or among laboratories?" Replicate or spike samples also can be used to answer a similar question.